

Telis Soliris Hand-Held Remote

Features

UP Button

The "my" button acts as a stop button when the awning is in motion. When the window covering is stationary, the "my" button brings it to the programmed favorite position.

DOWN Button

When left LED is lit the window covering will only react to wind control. When right LED is lit the window covering will react to both sun and wind control.

Channel Selector Button



Telis Soliris RTS
Hand-Held Remote
shown in Pure finish
Telis 4 Soliris RTS also available

Also available in multiple finishes:



Silver



Lounge



Patio

Programming
Button
(recessed)



Back view of Remote